LOCK STATUS INDICATOR PROMPTS

Picture	SKU	Channel Mode	Unlock	Error Unlock	Low Battery Alert
	HS0335	Press any key, long beep to unlock	Long beep	Three short beeps	After unlock, continuous beeping
	HS0335B	*Keypad blue, sensor pink	*Keypad blue, sensor green	Sensor red	Continuous beeping, keypad blue flashing
	HS0396	Channel LED green, sensor purple	Sensor flashes green twice, two beeps	Sensor red	Battery icon red, continuous beeping
	HS0398	Sensor purple, continuous beep	Sensor & unlock LED green, long beep	Sensor red	Alarm LED red, continuous beeping
	HS0395	Channel LED green, keys 9–0 off sequentially	Unlock LED green, keys 9–0 off sequentially	Indicator red	Battery icon red, continuous beeping
	HS0447	None	Keypad white, unlock LED green	X key red	Battery icon red

Picture	SKU	Channel Mode	Unlock	Error Unlock	Low Battery Alert
	HS0434	Sensor purple flash twice	Sensor blue, keys 9–0 off sequentially	Sensor red	Alarm LED red, continuous beeping
	HS0436	Sensor pink	Sensor green	Sensor red	Sensor red flashing, continuous beeping